

AQUATABS 3,5mg

EFFERVESCENT TABLETS
OF WATER PURIFYING FOR EMERGENCIES

Health



FEATURES

Aquatabs are effervescent tablets that dissolve rapidly in water in order to destroy the microorganisms that are the cause of diarrhea, typhoid, cholera, trachoma, didatitose, etc.

Aquatabs are produced according to specifications of International Public Health.

UTILIZATION

Aquatabs are used by the biggest humanitarian organizations in the world: as UN, UNICEF, International Red Cross, etc.

ADVANTAGES

- Safe
- Easy to use
- No Iodine
- No flavor, color or unpleasant odor

PROPERTIES

Aquatabs has as the active component "Sodium Dichloroisocyanurate" (NaDCC).

APPLICATION

Aquatabs are recommended to disinfect 1 litre of water.

Add 1 tablet in 1 litre of water and wait about 30 minutes before drinking.

Aquatabs should be used to disinfect clear water. On case of very dirty water, with sand deposits, it should be decant or filter before adding the tablets.



AQUATABS application example

TECHNICAL SPECIFICATIONS	
DILUTION	Not applicable
CHEMICAL NATURE	Sodium troclosene (NaDCC) and liaison agents.
SURFACTANTS	Not applicable
PHYSICAL STATE / COLOUR	White solid
ODOUR	Chlorine
PH	6 a 7 (in solution)
SOLUBILITY IN WATER	Complete
CLEANING PERFORMANCE	Not applicable
RINSING	No
FOAMING	No
WEIGHT TABLET	7 mg
FLASH POINT	Not concerned
CHEMICAL REACTION	Neutral
CLASSIFICATION	Not applicable
EXPIRATION	2 years. Stored in the original packaging. Protect from excessive sunlight. Avoid extreme temperatures.

Quality food product, in terms of cleaning materials and equipment that can be in contact with food products, a simple cleaning with potable water is enough before drying



APPLICATION MODE

Aquatabs are recommended to disinfect 1 litre of water.
Add 1 tablet in 1 litre of water and wait about 30 minutes before drinking.
Aquatabs should be used to disinfect clear water. On case of very dirty water, with sand deposits, it should be decant or filter before adding the tablets.



CAUTIONS

Chemical product: Always read the label before using. Close the packing after each use. Keep out of children reach. In case of contact with eyes and skin wash with clean water. Do not mix with other products.

Always make a test to determine the compatibility and the appropriate contact time.



PORTUGAL

Imporquímica- Indústria Portuguesa de Produção Química, S.A.
Zona Industrial Alto do Carvalhinho, Lote 11 - Apartado 39
2861-909 Moita - Portugal
Tel: +351 212 808 390 | Fax: +351 212 808 395
E-mail: info@imporquimica.pt

ANGOLA

Imporquímica Angola, SA.
Estrada do Zango/Viana Polo Industrial Tubogás
Armazéns 35 e 36 - Município de Viana, Luanda Angola
Tel.: +244 222 290 850 | Fax: +244 222 290 230
E-mail: angola@imporquimica.com

CAPE VERDE

Imporquímica Cabo Verde, Lda.
Armazém Achada Grande de Trás
Ilha de Santiago, Praia - Cabo Verde
Tel.: +238 939 07 48
E-mail: caboverde@imporquimica.com

MOZAMBIQUE

Imporquímica Moçambique, Lda.
Avenida Zedequias Manganhela, n.º 267, Prédio JAT IV
4º andar, Maputo - Moçambique
Tel.: +258 845 797 467
E-mail: mocambique@imporquimica.com

NIGERIA

Imporquímica Nigeria Chemicals, Ltd.
Plot 59 Trans Amadi Industrial Layout,
Port Harcourt, Rivers State, Nigeria
Tel: +234 (0) 84 556 004
E-mail: info@nigeria-chemicals.com



visit us
IMPORQUIMICA.COM

AQUATABS